

# Курс "ППП" 2011 осень

Трассировка МРІ программ

Знакомство:

Библиотека трассировки - mri1

Визуализатор трассы - TV

# План

- Интерфейс библиотеки `traci`
- Пример подготовки программы
- Просмотр трассы в TV1.0
- Выдача задания лабораторной работы №2

# Интерфейс библиотеки mpic1

## **MPI\_Init** - ....

**tracefiles** - specify temporary and/or permanent trace files (required. If node process 0 opens a tracefile, then data from other processes that have not done so will be funneled through process 0.)

**tracestatistics** - specify which user events to collect statistics for (optional)

**tracelevel** - specify level of tracing (optional, but no data collected if levels not set)

**tracenode** - begin tracing  
(sync option required if collecting data for ParaGraph;  
sync option not required if only collecting statistics)

**traceevent** - to record user events  
(optional, and called as often as needed)

**tracedata** - to record special user event data  
(optional, and called as often as needed)

**MPI\_Finalize** - turn off tracing, wait until all processes are finished,  
renormalize clocks if necessary, then flush trace data to  
disk one process at a time

**и еще** .....

# Интерфейс библиотеки mpic1

**void tracefiles(char \*tempfile, char \*permfile, int verbose)**

: used for specifying temporary and permanent disk storage for trace data

- tempfile is the prefix (including directory) of the name of the disk to be used for temporary storage of trace data. A suffix (the node number) is appended to make all temporary files unique. If a null string is specified for this parameter, a temporary file is not used.
- permfile is the name of the disk file where this node's trace data should be sent for "permanent" storage. If a null string is specified for this parameter, the data is sent to processor 0. If processor 0 does not specify a permanent tracefile name, the data sent to it or generated locally is not saved.
- verbose == 1, fields in trace records are labelled  
!= 1, fields are not labelled (ParaGraph-readable form)

# Интерфейс библиотеки mpic1

**void tracenode(int tracesize, int flush, int sync)**

: node initialization routine

- tracesize is the number of bytes to be allocated for data storage
- flush == 1, if space runs out, send the data to secondary storage and reinitialize  
== 2, if space runs out, overwrite the data  
otherwise, if space runs out, stop collecting data
- sync == 0, do nothing  
== 1, synchronize the processor clocks.

# Интерфейс библиотеки mpicl

**void tracelevel(int mpi, int user, int trace)**

: set the types of tracing data collected

- mpi: tracing level for MPI commands
- user: tracing level for user-specified events
- trace: tracing level for MPICL commands

if  $< 0$ , then instrumentation is disabled.

if  $\geq 0$ , then statistics are collected.

if  $> 0$ , then event records are generated.

# Интерфейс библиотеки mpicl

**void traceinfo (int \*remaining, int \*picl, int \*user, int \*trace)**

: get instrumentation information

- remaining: approximate number of event records that can be saved in the remaining free storage in the instrumentation work space
- mpi: tracing level for MPI commands
- user: tracing level for user-specified events
- trace: tracing level for MPICL commands

# Интерфейс библиотеки mpicl

## **void traceexit()**

: stop tracing

## **void traceflush()**

: send data to the temporary or permanent trace file and reinitialize the data storage area. (Implicitly called in MPI\_Finalize if instrumentation has ever been enabled.)



# Интерфейс библиотеки mpicl

**void traceevent(char \*recordstring, int event, int nparams,  
int \*params)**

: used to record information about a user-defined event

- recordstring: record the beginning ("entry"), ending ("exit"), or simple occurrence ("mark") of a user event, label the event ("label"), or write a message to the trace file immediately ("message").
- event: user-specified event identifier. It should be a nonnegative integer. If statistics for this event are to be collected, the event id should also be less than the "events" field specified in the call to tracestatistics.
- nparams: number of integers or characters (see the params description below) in the params data.
- params: The data associated with the "entry", "exit", and "mark" records should be integer. The data associated with the "label" and "message" records should be character.

# Интерфейс библиотеки mpic1

**void tracedata(int event, int dataid, char \*datatype, int items,  
char \*data)**

: used to save (additional) data associated with a user-defined event.

- event: user-specified event identifier. It should be a nonnegative integer.
- dataid: user-specified data identifier. This is used by the user to identify the data, and the only restriction is that it be an integer.
- datatype: character string indicating type of data. Supported data types are "character", "integer", "long", "float", "real", and "double".
- items: number of data elements (of the specified type )
- data: user event data, or specified type.

# Пример подготовки программы

```
#include <pcontrol.h>
```

```
/* enable tracing */
```

```
MPI_Pcontrol(TRACEFILES, "", "tracefile", 0);
```

```
MPI_Pcontrol(TRACELEVEL, 1, 1, 1);
```

```
MPI_Pcontrol(TRACENODE, 1000000, 0, 1);
```

```
MPI_Pcontrol(TRACEEVENT, "mark", 0, 0, "");
```

```
MPI_Pcontrol(TRACEEVENT, "entry", 1, 0, "");
```

```
MPI_Pcontrol(TRACEEVENT, "exit", 1, 0, "");
```

# Пример подготовки программы

- Компилировать с библиотекой `mpicl`
  - Использовать **`mpicc-TV aa.c -o aa`**
- Запустить обычным образом
- Отсортировать трассу
  - Использовать **`tracesort tracefile`**

# Просмотр трассы в TV1.0

Просмотр трассы на рабочем месте

- Загрузить TV 1.0
- Перенести файл трассы на локальную машину
- Применить п.1. к п.2.